



Boothill Speedway 2020 Beginner Rules

Division Rules

1. RaceCeiver required at all times.
2. Boothill Factory Stock Technical and Safety Rules apply, and drivers must utilize cars that comply with the technical specifications of the Factory Stock class.
3. Boothill Speedway will run a single 10 Lap race for Beginners if 6 or more drivers have entered before registration closes nightly.
4. If there are less than 6 cars signed in for Beginners on any given night, those drivers will be placed on the back of the Factory Stock heat races if they so choose.
5. The Beginner's class is for a competitor to learn car control, spatial awareness on the racetrack, and to be comfortable on the speedway in a competitive situation if a driver is new to the sport and does not feel ready to compete in the Factory Stock Division. It is not a requirement of Boothill Speedway for competitors to begin in this division.
6. The division is will not award money, points, or any other winnings based upon finishing position.

Eligibility

1. Participants eligible for the Beginners class must not be older than 18.
2. Drivers cannot have more than 2 Feature wins at Boothill or competed in no more than 10 Beginner races at Boothill.
3. Once a Beginner wins 2 races or competes in 10 Beginner races without a win, they must move up to the Factory Stock class.
4. A driver will not be able to compete in both classes on the same evening and once a driver competes with the Factory Stock class (and a Beginners event is being run on the same race card), they are not allowed to drop back and compete with the Beginners moving forward.
5. Boothill Speedway reserves the right to refuse entry to the Beginner's division and place any entrant into the Factory Stock class.